



**NOTES:**

1. AFTER PLANTING, PRUNE ONLY CROSSOVER LIMBS, CO-DOMINANT LEADERS, BROKEN OR DEAD BRANCHES.
2. WATER THOROUGHLY WHILE BACKFILLING TO ELIMINATE AIR POCKETS. RE-WATER AFTER PLANTING.
3. REMOVE ALL STRING, TWINE AND TAGS FROM TRUNK AND BRANCHES.
4. PENETRATE SUBSOIL BUT DO NOT PENETRATE ROOT BALL WITH STAKES.
5. AFTER PLANTING, INSTALL 20-GALLON SLOW RELEASE WATERING BAG.

**TREE PLANTING DETAIL**

N. T. S.